| | | BATTERY PACKS | | | | | | | | | | | |
|--|--|--|--|--|---|--|---|--|---|--|--|--|--|
| MODEL NAME | BP-292UL Li-ion 72 V/1910 mAh (min.) 2010 mAh (typ.) | BP-300 Li-ion 72 V/2200 mAh (min.) 2350 mAh (typ.) | BP-303 Lion 72 V/3200 mAh (min.) 3350 mAh (typ.) | BP-283 Li-ion 72 V/1910 mAh (min.) 2010 mAh (typ.) | BP-284 Li-ion 72 V/3070 mAh (min.) 3210 mAh (typ.) | BP-294 Li-ion 72 V/3050 mAh (min.) 3150 mAh (typ.) | BP-290 Li-ion 72 V/1910 mAh (min.) 2010 mAh (typ.) | BP-280 Li-ion 72 V/2280 mAh (min.) 2400 mAh (typ.) | BP-279 Li-ion 72 V/1485 mAh (min.) 1570 mAh (typ.) | | | | |
| IC-SAT100 | | ~ | | | | | ~ | | | | | | |
| IP730D, IP740D | | | ~ | | | | | | | | | | |
| IP501H, IP504H | | | | | | | | | | | | | |
| IP100H | | | | | | | | | | | | | |
| IC-F7010T/S, IC-F7020T/S, IC-F7040T/S | | | | ✓ | ✓ | | | | | | | | |
| IC-F3400DT/DS/D, IC-F4400DT/DS/D | | | | ~ | ~ | | | | | | | | |
| IC-F3261DT/DS, IC-F3263DT/DS IC-F4261DT/DS, IC-F4263DT/DS | | | | | | | | | | | | | |
| IC-F52D, IC-F62D | | | | | | ~ | ~ | | | | | | |
| IC-F1100DT/DS/D, IC-F2100DT/DS/D | | | | | | | | ✓ | ✓ | | | | |
| IC-F3230DT/DS, IC-F4230DT/DS | | | | | | | | | | | | | |
| IC-F52D-UL, IC-F62D-UL | ~ | | | | | | | | | | | | |
| IC-F1000/T/S, IC-F2000/T/S, IC-V10MR | | | | | | | | ✓(For IC-F1000/IC-F2000series) ^{*1} | ✓ | | | | |
| IC-F3001, IC-F3003 IC-F4001, IC-F4003, IC-V3MR | | | | | | | | | | | | | |

| | | | BATTER | Y PACKS | | | В | BATTERY CASES | | | |
|--|--|---|---|---|---|--|-----------------------------|-----------------------------|-------------------------------|--|--|
| MODEL NAME | BP-278 Li-ion 72 V/1130 mAh (min.) 1190 mAh (typ.) | BP-232WP Li-ion 74 V/2200 mAh (min.) 2350 mAh (typ.) | BP-265 Li-ion 74 V/1850 mAh (min.) 2000 mAh (typ.) | BP-271 Li-ion 74 V/1150 mAh (min.) 1200 mAh (typ.) BP-272 Li-ion 74 V/1880mAh (min.) 2000 mAh (typ.) | BP-298 Li-ion 72 V/3200 mAh (min.) 3350 mAh (typ.) | BP-307 Li-ion 72 V/3050 mAh (min.) 3150 mAh (typ.) | BP-305 LR6 (AA) ×5 cells | BP-291 LR6 (AA) ×5 cells | BP-240 LR03 (AAA) ×6 cells | | |
| IC-SAT100 | | | | | | | | | | | |
| IP730D, IP740D | | | | | | | ✓ | | | | |
| IP501H, IP504H | | | | ✓ | | ✓ | | | | | |
| IP100H | | | | ~ | | ✓ | | | | | |
| IC-F7010T/S, IC-F7020T/S, IC-F7040T/S | | | | | | | | | | | |
| IC-F3400DT/DS/D, IC-F4400DT/DS/D | | | | | | | | | | | |
| IC-F3261DT/DS, IC-F3263DT/DS IC-F4261DT/DS, IC-F4263DT/DS | | ~ | | | | | | | ✓ | | |
| IC-F52D, IC-F62D | | | | | | | | ~ | | | |
| IC-F1100DT/DS/D, IC-F2100DT/DS/D | ~ | | | | | | | | | | |
| IC-F3230DT/DS, IC-F4230DT/DS | | ~ | | | | | | | ✓ | | |
| IC-F52D-UL, IC-F62D-UL | | | | | | | | | | | |
| IC-F1000/T/S, IC-F2000/T/S, IC-V10MR | ✔(For IC-F1000/IC-F2000series)*1 | | | | | | | | | | |
| IC-F3001, IC-F3003 IC-F4001, IC-F4003, IC-V3MR | | | ✔(For IC-F3001/IC-F4001series)*2 | | ✔(For IC-V3MR) | | | | | | |

| | В | ATTERY CASE | S | CHARGERS | | | | | | |
|--|-----------------------------|-----------------------------|------------------------------------|---------------------------------------|----------------------------|---|---|---------------------------------------|---------------------------------------|--|
| MODEL NAME | BP-261 LR6 (AA) x6 cells | BP-263 LR6 (AA) ×6 cells | BP-273 LR6 (AA) ×3 cells | BC-241 ^{*4} Rapid charger | BC-219N*4 Rapid charger | BC-225 ^{*4} Intelligent charger | BC-226 Rapid charger Connectable type | BC-227 ^{*4} Rapid charger | BC-213 ^{*4} Rapid charger | |
| | | | | | | | | | | |
| IC-SAT100 | | | | ~ | | | | | | |
| IP730D, IP740D | | | | | | | ~ | ~ | | |
| IP501H, IP504H | | | | | | | | | | |
| IP100H | | | ~ | | | | | | | |
| IC-F7010T/S, IC-F7020T/S, IC-F7040T/S | | | | | ~ | ~ | | ~ | | |
| IC-F3400DT/DS/D, IC-F4400DT/DS/D | | | | | ✓ | V | ~ | ✓ | | |
| IC-F3261DT/DS, IC-F3263DT/DS IC-F4261DT/DS, IC-F4263DT/DS | ~ | | | | | | | | | |
| IC-F52D, IC-F62D | | | | | ~ | ✓ | ~ | ~ | | |
| IC-F1100DT/DS/D, IC-F2100DT/DS/D | | | | | | | | | ✓ | |
| IC-F3230DT/DS, IC-F4230DT/DS | ~ | | | | | | | | | |
| IC-F52D-UL, IC-F62D-UL | | | | | | | ✓*3 | ✓*3 | | |
| IC-F1000/T/S, IC-F2000/T/S, IC-V10MR | | | | | | | | | V | |
| IC-F3001, IC-F3003 IC-F4001, IC-F4003, IC-V3MR | | ~ | | | | | | | | |

*¹ Except IC-V10MR *² Except IC-V3MR *³ The battery charger, BC-226, or BC-227 **must not be used** in an explosive atmosphere. *⁴ AC adapter supplied, depending on charger version. The IC-F52D-UL/IC-F62D-UL models should only be used with the specified approved options.

| | | | READER SOFTWARE | MULTI-CHARGERS | | | | | |
|--|---------------------------|---|---|---|---|--|--|--|--|
| MODEL NAME | BC-160*4 Rapid charger | BC-193*4 Rapid charger for BP-265 | BC-240 ^{*4} Rapid charger for BP-298 | BC-202IP3L Connectable type Connects up to six BC-202IP3L units. | BC-202 ^{*4} Rapid charger BC-202IP2 ^{*4} Rapid charger with smart charging function | BC-218 ^{*4} Rapid charger with Bluetooth [®] function | RS-BC225 Intelligent charger software for Windows [™] PC | BC-214N ⁻⁴ Either AD-130 AD-132N or AD-140 is supplied with the BC-214N. | BC-214*4 AD-130 is supplied with the BC-214, depending on version |
| IC-SAT100 | | | | | (Photo shows BC-202IP2) | | | (#30/31, AD-140 installed) | - |
| IP730D, IP740D | | | | | | | | ✔ (#62/63, AD-132N installed) | |
| IP501H, IP504H | | | | ~ | ~ | ~ | | | |
| IP100H | | | | ~ | ~ | | | | |
| IC-F7010T/S, IC-F7020T/S, IC-F7040T/S | | | | | | | ✔(Use with BC-225) | (#62/63, AD-132N installed) | |
| IC-F3400DT/DS/D, IC-F4400DT/DS/D | | | | | | | (Use with BC-225) | ✔ (#62/63, AD-132N installed) | |
| IC-F3261DT/DS, IC-F3263DT/DS IC-F4261DT/DS, IC-F4263DT/DS | ~ | | | | | | | | |
| IC-F52D, IC-F62D | | | | | | | (Use with BC-225) | ✔ (#62/63, AD-132N installed) | |
| IC-F1100DT/DS/D, IC-F2100DT/DS/D | | | | | | | | (#42/43, AD-130 installed) | ✔ (#42/43, AD-130 installed |
| IC-F3230DT/DS, IC-F4230DT/DS | ~ | | | | | | | | |
| IC-F52D-UL, IC-F62D-UL | | | | | | | | | |
| IC-F1000/T/S, IC-F2000/T/S, IC-V10MR | | | | | | | | (#42/43, AD-130 installed) | ✔ (#42/43, AD-130 installed |
| IC-F3001, IC-F3003 IC-F4001, IC-F4003, IC-V3MR | | ✔(For IC-F3001/IC-F4001series)*2 | ✔(For IC-V3MR) | | | | | (#27/28, AD-139 installed for IC-V3MR) | |

| | MULTI-CH | IARGERS | | | AC ADA | APTERS | | | CHARGER CABLES |
|--|--|--------------------|---------------------------------|--------------------------------------|--|-----------------------|-------------------------|-----------------------|-------------------------------|
| MODEL NAME | BC-197*4 Either AD-121, AD-122 is supplied with the BC-197, depending on version. | BC-211*4 | BC-242 12 V/1 A | BC-1235"5 12 V/1A L-shape plug | BC-1235 ⁻⁵ 12 V/1 A straight plug for BC-226/BC- 2021P3Lsingleunit | BC-1575 12 V/75 A | BC-228 15 V/4 A | BC-2075 12 V/4.2 A | CP-23L For 12 V DC |
| IC-SAT100 | | | ✔(Use with BC-241) | | • | (Use with BC-214N) | | | |
| IP730D, IP740D | | | | (Use with BC-227) | ✔ (Use with BC-226) | ✔ (Use with BC-214N) | (Use with BC-226) | | (Use with BC-227) |
| IP501H, IP504H | | (AD-127 installed) | | ✔(Use with BC-202/IP2) | ✔(Use with BC-202IP3L) | (Use with BC-211) | V (Use with BC-202IP3L) | (Use with BC-218) | (Use with BC-218) |
| IP100H | | (AD-127 installed) | | ✔(Use with BC-202/IP2) | ✔(Use with BC-202IP3L) | (Use with BC-211) | (Use with BC-202IP3L) | | |
| IC-F7010T/S, IC-F7020T/S, IC-F7040T/S | | | | (Use with BC-225, BC-227 or BC-219N) | | V (Use with BC-214N) | | | (Use with BC-219N or BC-227) |
| IC-F3400DT/DS/D, IC-F4400DT/DS/D | | | | (Use with BC-225, BC-227 or BC-219N) | ✔(Use with BC-226) | (Use with BC-214N) | (Use with BC-226) | | (Use with BC-219N or BC-227) |
| IC-F3261DT/DS, IC-F3263DT/DS IC-F4261DT/DS, IC-F4263DT/DS | (#22/23, AD-122 installed) | | | ✔(Use with BC-160) | | V (Use with BC-197) | | | (Use with BC-160) |
| IC-F52D, IC-F62D | | | | (Use with BC-225, BC-227 or BC-219N) | ✔(Use with BC-226) | (Use with BC-214N) | (Use with BC-226) | | (Use with BC-219N or BC-227) |
| IC-F1100DT/DS/D, IC-F2100DT/DS/D | | | (Use with BC-213) | (Use with BC-213) | | (Use with BC-214/N) | | | (Use with BC-213) |
| IC-F3230DT/DS, IC-F4230DT/DS | ✔ (#22/23, AD-122 installed) | | | (Use with BC-160) | | (Use with BC-197) | | | (Use with BC-160) |
| IC-F52D-UL, IC-F62D-UL | | | | ✔(Use with BC-227) | | | (Use with BC-226) | | (Use with BC-227) |
| IC-F1000/T/S, IC-F2000/T/S, IC-V10MR | | | (Use with BC-213) | ✔(Use with BC-213) | | V (Use with BC-214/N) | | | (Use with BC-213) |
| IC-F3001, IC-F3003 IC-F4001, IC-F4003, IC-V3MR | (#12/13, AD-121 installed for IC-F3001/IC-F4001) | | ✔ (Use with BC-240 for IC-V3MR) | (Use with BC-191) | | (Use with BC-197) | | | ✔ (Use with BC-193 or BC-240) |

| | CHARGE | R CABLES | DC POWER CABLES | | | |
|--|----------------------------------|-------------------------|--|--------------------------------|--|--|
| MODEL NAME | CP-22 With DC-DC CONVERTER | CP-25H For 12 V DC | OPC-515L | OPC-656 | | |
| IC-SAT100 | | | | V (Use with BC-214N) | | |
| IP730D, IP740D | | | V (Use with BC-227) | V (Use with BC-214N) | | |
| IP501H, IP504H | V (Use with BC-218) | V (Use with BC-202IP3L) | | | | |
| IP100H | | V (Use with BC-202IP3L) | | | | |
| IC-F7010T/S, IC-F7020T/S, IC-F7040T/S | | | V (Use with BC-219N, BC-225 or BC-227) | (Use with BC-214N) | | |
| IC-F3400DT/DS/D, IC-F4400DT/DS/D | | | V (Use with BC-219N, BC-225 or BC-227) | V (Use with BC-214N) | | |
| IC-F3261DT/DS, IC-F3263DT/DS IC-F4261DT/DS, IC-F4263DT/DS | | | V (Use with BC-160) | V (Use with BC-197) | | |
| IC-F52D, IC-F62D | | | V (Use with BC-219N, BC-225 or BC-227) | V (Use with BC-214N) | | |
| IC-F1100DT/DS/D, IC-F2100DT/DS/D | | | | V (Use with BC-214/N) | | |
| IC-F3230DT/DS, IC-F4230DT/DS | | | V (Use with BC-160) | (Use with BC-197) | | |
| IC-F52D-UL, IC-F62D-UL | | | (Use with BC-227) | | | |
| IC-F1000/T/S, IC-F2000/T/S, IC-V10MR | | | | V (Use with BC-214/N) | | |
| IC-F3001, IC-F3003 IC-F4001, IC-F4003, IC-V3MR | | | V (Use with BC-193 or BC-240) | V (Use with BC-197 or BC-214N) | | |

*5 BC-123 for the USA plug. SE for European plug. SV for Australian plug.

| | | SPEAKER-MICROPHONES | | | | | | | | | | |
|--|---|---------------------|-----------------------|-------------------------------------|-----------------------|-----------------------------------|----------|-----------------------|--|--|--|--|
| MODEL NAME | HM-245T With SUB PTT button Available later | HM-236 | HM-184UL | HM-222H BTL speaker-microphone*6 | HM-184/H | HM-168LWP Waterproof connector | HM-158LA | HM-159LA | HM-222HLWP BTL speaker-microphone*6 | | | |
| IC-SAT100 | | | | ✓ | | | | | | | | |
| IP730D, IP740D | v | ~ | | ~ | V | | | | | | | |
| IP501H, IP504H | | | | | | | | | | | | |
| IP100H | | | | | | | | | | | | |
| IC-F7010T/S, IC-F7020T/S, IC-F7040T/S | | | | ~ | | | | | | | | |
| IC-F3400DT/DS/D, IC-F4400DT/DS/D | | | | ✓ | | | | | | | | |
| IC-F3261DT/DS, IC-F3263DT/DS IC-F4261DT/DS, IC-F4263DT/DS | | | | | ✓ | | | | | | | |
| IC-F52D, IC-F62D | | | | ~ | | | | | | | | |
| IC-F1100DT/DS/D, IC-F2100DT/DS/D | | | | | | ~ | ~ | ✓ | ✓ | | | |
| IC-F3230DT/DS, IC-F4230DT/DS | | | | | | ~ | ~ | ~ | ~ | | | |
| IC-F52D-UL, IC-F62D-UL | | | ✓ | | | | | | | | | |
| IC-F1000/T/S, IC-F2000/T/S, IC-V10MR | | | | | | ~ | ~ | ✓ | ✓ | | | |
| IC-F3001, IC-F3003 IC-F4001, IC-F4003, IC-V3MR | | | | | | | ~ | ✓ | ✓ | | | |

| | | SPEAKER-MI | ICROPHONES | | | EARPHONE-M | IICROPHONES | | TIE-CLIP MICROPHONES |
|--|-------------------------------------|------------|------------|-------------------|----------|------------|-------------|----------|---------------------------------|
| MODEL NAME | HM-222HLS BTL speaker-microphone | HM-183LS | HM-186LS | нм-215 | HM-153LA | HM-166LA | HM-153LS | HM-166LS | HM-238MC With SUB PTT button |
| IC-SAT100 | | | | | | | | | |
| IP730D, IP740D | | | | | | | | | ~ |
| IP501H, IP504H | (For IP504H) | ~ | V | (Use with BC-218) | | | ~ | ~ | |
| IP100H | | ~ | V | | | | ✔*7 | ✓*7 | |
| IC-F7010T/S, IC-F7020T/S, IC-F7040T/S | | | | | | | | | |
| IC-F3400DT/DS/D, IC-F4400DT/DS/D | | | | | | | | | |
| IC-F3261DT/DS, IC-F3263DT/DS IC-F4261DT/DS, IC-F4263DT/DS | | | | | | | | | |
| IC-F52D, IC-F62D | | | | | | | | | |
| IC-F1100DT/DS/D, IC-F2100DT/DS/D | | | | | ~ | ~ | | | |
| IC-F3230DT/DS, IC-F4230DT/DS | | | | | | ~ | | | |
| IC-F52D-UL, IC-F62D-UL | | | | | | | | | |
| IC-F1000/T/S, IC-F2000/T/S, IC-V10MR | | | | | ~ | ~ | | | |
| IC-F3001, IC-F3003 IC-F4001, IC-F4003, IC-V3MR | | | | | | | | | |

| | TIE-CLIP MICROPHONES | | | | HEADSETS | | | |
|--|-----------------------|---|---|-----------------------------------|--|--|-------------------------------------|----------------------------|
| MODEL NAME | HM-163MC | HS-94 Earhook type with boom microphone | HS-94LWP Earhook type with waterproof connector | HS-95 Behind-the-head type | HS-95LWP Behind-the-head type with waterproof connector | HS-97 Throat microphone type | HS-102 Earphone type | VS-3 Bluetooth® headset |
| IC-SAT100 | ✓ | (Use with VS-5MC) | | ✔ (Use with VS-5MC) | | ✔ (Use with VS-5MC) | | ✓ |
| IP730D, IP740D | ~ | (Use with VS-5MC) | | (Use with VS-5MC) | | ✔ (Use with VS-5MC) | | ~ |
| IP501H, IP504H | | (Use with OPC-2006LS or OPC-2328) | | (Use with OPC-2006LS or OPC-2328) | | (Use with OPC-2006LS or OPC-2328) | V (Use with OPC-2359) | ✓ |
| IP100H | | (Use with OPC-2006LS or OPC-2328) | | Use with OPC-2006LS or OPC-2328) | | Use with OPC-2006LS or OPC-2328) | ✓* ⁷ (Use with OPC-2359) | |
| IC-F7010T/S, IC-F7020T/S, IC-F7040T/S | ✓ *8 | ✓* ¹⁰ (Use with VS-4MC or VS-5MC) | | ✓*10(Use with VS-4MC or VS-5MC) | | ✓ ^{★10} (Use with VS-4MC or VS-5MC) | | ✓ |
| IC-F3400DT/DS/D, IC-F4400DT/DS/D | | (Use with VS-4MC) | | V (Use with VS-4MC) | | (Use with VS-4MC) | | |
| IC-F3261DT/DS, IC-F3263DT/DS IC-F4261DT/DS, IC-F4263DT/DS | | (Use with VS-4MC) | | (Use with VS-4MC) | | (Use with VS-4MC) | | |
| IC-F52D, IC-F62D | ~ | (Use with VS-5MC) | | (Use with VS-5MC) | | (Use with VS-5MC) | | ✓ |
| IC-F1100DT/DS/D, IC-F2100DT/DS/D | | Use with VS-4LA or OPC-2004LA) | v | (Use with VS-4LA or OPC-2004LA) | ✓ | (Use with VS-4LA or OPC-2004LA) | | |
| IC-F3230DT/DS, IC-F4230DT/DS | | V (Use with VS-4LA) | | V (Use with VS-4LA) | | (Use with VS-4LA) | | |
| IC-F52D-UL, IC-F62D-UL | | | | | | | | |
| IC-F1000/T/S, IC-F2000/T/S, IC-V10MR | | (Use with VS-4LA or OPC-2004LA) | ~ | Use with VS-4LA or OPC-2004LA) | ~ | (Use with VS-4LA or OPC-2004LA) | | |
| IC-F3001, IC-F3003 IC-F4001, IC-F4003, IC-V3MR | | (Use with VS-4LA or OPC-2004LA) | | (Use with VS-4LA or OPC-2004LA) | | (Use with VS-4LA or OPC-2004LA) | | |

⁴⁶ Increased speaker-microphone volume depends on the combination of the transceiver and microphone. Ask your dealer for possible combination.
 ⁴⁷ Requires either HM-153LS, HM-166LS or HS-102 with OPC-2359 for full-duplex operation.
 ⁴⁸ For IC-F7040T/S only.
 ⁴⁹ HS-94, HS-95 and HS-97 headsets are simplex mode operation only.
 ⁴¹⁰ VS-4MC for IC-F7010/IC-F7020 series, VS-5MC for IC-F7040 series.

| | | PTT SWITCH CABLES | | | PLUG ADAP | TER CABLES | EARPHONES | | |
|--|---------------------------------------|--|---------------------------------------|---|---------------------|------------------------------------|------------------------------------|----------------------------------|----------------------------------|
| MODEL NAME | VS-4MC For manual PTT operation | VS-5MC For manual PTT, VOX operation | VS-4LA For manual PTT operation | OPC-2328 For manual PTT operation | OPC-2359 | OPC-2004LA For VOX operation | OPC-2006LS For VOX operation | EH-15B 2.5 mm plug | SP-26 2.5 mm plug |
| | 0 | 0 | 0 | 00 | 0.5 | | \bigcirc | _ 0 | |
| IC-SAT100 | | V (Use with HS-94, HS-95 or HS-97) | | | | | | ✔ (Use with HM-163MC) | ✔(Use with HM-163MC) |
| IP730D, IP740D | | V (Use with HS-94, HS-95 or HS-97) | | | | | | V(Use with HM-163MC or HM-238MC) | ✔(Use with HM-163MC or HM-238MC) |
| IP501H, IP504H | | | | V (Use with HS-94, HS-95 or HS-97) | V (Use with HS-102) | | V (Use with HS-94, HS-95 or HS-97) | | |
| IP100H | | | | V (Use with HS-94, HS-95 or HS-97) | V (Use with HS-102) | | V (Use with HS-94, HS-95 or HS-97) | | |
| IC-F7010T/S, IC-F7020T/S, IC-F7040T/S | V*11 (Use with HS-94, HS-95 or HS-97) | 12 (Use with HS-94, HS-95 or HS-97) | | | | | | ✓*11 (Use with HM-163MC) | ✓*11 (Use with HM-163MC) |
| IC-F3400DT/DS/D, IC-F4400DT/DS/D | V (Use with HS-94, HS-95 or HS-97) | | | | | | | | |
| IC-F3261DT/DS, IC-F3263DT/DS IC-F4261DT/DS, IC-F4263DT/DS | V (Use with HS-94, HS-95 or HS-97) | | | | | | | | |
| IC-F52D, IC-F62D | | (Use with HS-94, HS-95 or HS-97) | | | | | | (Use with HM-163MC) | ✔ (Use with HM-163MC) |
| IC-F1100DT/DS/D, IC-F2100DT/DS/D | | | V (Use with HS-94, HS-95 or HS-97) | | | V (Use with HS-94, HS-95 or HS-97) | | | |
| IC-F3230DT/DS, IC-F4230DT/DS | | | V (Use with HS-94, HS-95 or HS-97) | | | | | | |
| IC-F52D-UL, IC-F62D-UL | | | | | | | | | |
| IC-F1000/T/S, IC-F2000/T/S, IC-V10MR | | | V (Use with HS-94, HS-95 or HS-97) | | | V (Use with HS-94, HS-95 or HS-97) | | | |
| IC-F3001, IC-F3003 IC-F4001, IC-F4003, IC-V3MR | | | V (Use with HS-94, HS-95 or HS-97) | | | V (Use with HS-94, HS-95 or HS-97) | | | |

| | | | EARPHONES | | | ACC AD | APTERS | BELT CLIPS | |
|--|---------------------------------------|----------------------------------|---|------------------------------------|---------------------------------------|---|---|---|----------------|
| MODEL NAME | SP-27 3.5 mm plug | SP-28 2.5 mm plug | SP-29 3.5 mm plug | SP-32 Tube earphone adapter | SP-40 3.5 mm plug | AD-118 Allows you to use 6-pin Hirose plug accessories | AD-135 3.5 mm jack earphone adapter | MB-135 MB-133 MB-127 MB-124 MB-94R MBB-3 MBB-5 Alligator type (Photo shows MB-139) | |
| IC-SAT100 | ✔ (Use with HM-222H or AD-135) | V (Use with HM-163MC) | (Use with HM-222H or AD-135) | (Use with EH-15B) | ✔(Use with HM-222H or AD-135) | ~ | ~ | V (Use MBB-5) | |
| IP730D, IP740D | (Use with HM-222H, HM-245T or AD-135) | V(Use with HM-163MC or HM-238MC) | Use with HM-222H, HM-245T or AD-135) | | (Use with HM-222H, HM-245T or AD-135) | | ~ | V (Use MB-133) | V (Use MB-136) |
| IP501H, IP504H | | | | | | | | V (Use MB-135) | |
| IP100H | | | | | | | | V (Use MB-127) | |
| IC-F7010T/S, IC-F7020T/S, IC-F7040T/S | V*12(Use with HM-222H or AD-135) | ✓*12(Use with HM-163MC) | ✔* ¹² (Use with HM-222H or AD-135) | ✓* ¹² (Use with EH-15B) | ✓*12(Use with HM-222H or AD-135) | ~ | ✔* ¹² | V (Use MB-133) | V (Use MB-136) |
| IC-F3400DT/DS/D, IC-F4400DT/DS/D | | | | | | ~ | | V (Use MB-133) | V (Use MB-136) |
| IC-F3261DT/DS, IC-F3263DT/DS IC-F4261DT/DS, IC-F4263DT/DS | | | | | | ~ | | (Use MB-94R) | V (Use MB-93) |
| IC-F52D, IC-F62D | ✔ (Use with HM-222H or AD-135) | (Use with HM-163MC) | (Use with HM-222H or AD-135) | (Use with EH-15B) | ✔(Use with HM-222H or AD-135) | ~ | ~ | V (Use MBB-3) | V (Use MB-136) |
| IC-F1100DT/DS/D, IC-F2100DT/DS/D | | | | | | | | V (Use MB-133) | |
| IC-F3230DT/DS, IC-F4230DT/DS | | | | | | | | (Use MB-94R) | 🖌 (Use MB-93) |
| IC-F52D-UL, IC-F62D-UL | | | | | | | | V (Use MBB-3) | V (Use MB-136) |
| IC-F1000/T/S, IC-F2000/T/S, IC-V10MR | | | | | | | | V (Use MB-133) | |
| IC-F3001, IC-F3003 IC-F4001, IC-F4003, IC-V3MR | | | | | | | | V (Use MB-124) | |

| | E | BELT HANGER | S | CHARGER BRACKET | MOUNT BASE | UNT BASE BRACKET ADAPTOR | | NG CASES |
|--|-----------------------|-----------------------|-----------------------|---------------------|---------------------------------|---------------------------------|-----------|-----------------------|
| MODEL NAME | MB-96N Swivel type | MB-96F Fixed type | MB-96FL Long type | MB-130 | MBF-1 For use with BC-218 | MBA-7 For use with BC-218 | LC-195*13 | LC-191* ¹³ |
| | | | | | S | | | |
| IC-SAT100 | | | | | | | | |
| IP730D, IP740D | v | ~ | ~ | | | | ~ | |
| IP501H, IP504H | | | | | (Use with MBA-7) | (Use with MBF-1) | | |
| IP100H | | | | | | | | |
| IC-F7010T/S, IC-F7020T/S, IC-F7040T/S | ✓ | ✓ | ~ | | | | | |
| IC-F3400DT/DS/D, IC-F4400DT/DS/D | ~ | ~ | ~ | | | | | |
| IC-F3261DT/DS, IC-F3263DT/DS IC-F4261DT/DS, IC-F4263DT/DS | ✓ | ~ | ✓ | (Use with BC-160) | | | | |
| IC-F52D, IC-F62D | ~ | ~ | ~ | | | | | |
| IC-F1100DT/DS/D, IC-F2100DT/DS/D | | | | (Use with BC-213) | | | | |
| IC-F3230DT/DS, IC-F4230DT/DS | v | ~ | | ✔ (Use with BC-160) | | | | |
| IC-F52D-UL, IC-F62D-UL | ~ | V | ~ | | | | | ✓ |
| IC-F1000/T/S, IC-F2000/T/S, IC-V10MR | | | | ✔(Use with BC-213) | | | | |
| IC-F3001, IC-F3003 IC-F4001, IC-F4003, IC-V3MR | | | | ✔(Use with BC-193) | | | | |

*¹⁰ VS-4MC for IC-F7010/IC-F7020 series, VS-5MC for IC-F7040 series.*¹¹ For IC-F7010/IC-F7020 series only *¹² For IC-F7040T/S only. *¹³ Charging is possible while the case is attached.

| | | | CARRYIN | IG CASES | | | STRAP | DOCKING STATION |
|--|-----------------------|-----------|--|-------------------------------|----------------------------------|----------------------------------|-------------------------------|------------------------------|
| MODEL NAME | LC-184* ¹³ | LC-186*13 | LC-187*13 For use with BP-290 LC-190*13 For use with BP-294 | LC-188 For use with BP-290 | LC-183*13 For use with BP-271 | LC-185*13 For use with BP-272 | MB-57L Long shoulder strap | BC-247*15 Charging cradle |
| IC-SAT100 | | | | | | | | ✓ |
| IP730D, IP740D | | | | | | | (Use with LC-195) | |
| IP501H, IP504H | | | | | ✓ | ~ | ✔ (Use with LC-183 or LC-185) | |
| IP100H | | | | | | | | |
| IC-F7010T/S, IC-F7020T/S, IC-F7040T/S | ✓ | | | | | | | |
| IC-F3400DT/DS/D, IC-F4400DT/DS/D | *14 | *14 | | | | | | |
| IC-F3261DT/DS, IC-F3263DT/DS IC-F4261DT/DS, IC-F4263DT/DS | | | | | | | | |
| IC-F52D, IC-F62D | | | ~ | ~ | | | | |
| IC-F1100DT/DS/D, IC-F2100DT/DS/D | | | | | | | | |
| IC-F3230DT/DS, IC-F4230DT/DS | | | | | | | | |
| IC-F52D-UL, IC-F62D-UL | | | | | | | | |
| IC-F1000/T/S, IC-F2000/T/S, IC-V10MR | | | | | | | | |
| IC-F3001, IC-F3003 IC-F4001, IC-F4003, IC-V3MR | | | | | | | | |

| | | AN | TENNAS | | | CUT AN | TENNAS | HIGH GAIN ANTENNAS |
|--|---|--|--|---|-------------------------|--|--|--|
| MODEL NAME | FA-S81V 136-150 MHz FA-S82V 148-162 MHz FA-S82V 160-174 MHz FA-S81U 380-430 MHz FA-S82U 430-480 MHz FA-S82U 430-480 MHz 470-520 MHz | FA-SC25V 136–150 MHz FA-SC55V 150–174 MHz FA-SC52V 150–174 MHz FA-SC52V 150–174 MHz FA-SC52V 400–430 MHz FA-SC57U 430–470 MHz FA-SC72U 470–520 MHz | FA-SC28V 148-162 MHz FA-SC29V 160-174 MHz | FA-SC01U 350-400 MHz FA-SC02U 330-380 MHz FA-SC03U 380-430 MHz | FA-S100U 760-870 MHz | FA-S67VC 136-174 MHz FA-S76UC 380-520 MHz | FA-SC61VC 136-174 MHz FA-SC61UC 380-520 MHz | FA-SC62V 150-160 MHz FA-SC63V 155-165 MHz |
| IC-SAT100 | | | | | | | | |
| IP730D, IP740D | | ✓ | ~ | ~ | | | ~ | V |
| IP501H, IP504H | | | | | | | | |
| IP100H | | | | | | | | |
| IC-F7010T/S, IC-F7020T/S, IC-F7040T/S | ✓ | | | | ~ | ~ | | |
| IC-F3400DT/DS/D, IC-F4400DT/DS/D | ~ | | | | | ~ | | |
| IC-F3261DT/DS, IC-F3263DT/DS IC-F4261DT/DS, IC-F4263DT/DS | | ✓ | | V (Use FA-SC01U or FA-SC03U) | | | ✓ | V |
| IC-F52D, IC-F62D | | (Except FA-SC55V) | ~ | V (Use FA-SC01U) | | | ~ | ✓ |
| IC-F1100DT/DS/D, IC-F2100DT/DS/D | | ✓ | ✓ | ✔ (Use FA-SC01U or FA-SC02U) | | | ✓ | |
| IC-F3230DT/DS, IC-F4230DT/DS | | v | | V (Use FA-SC01U or FA-SC03U) | | | ~ | v |
| IC-F52D-UL, IC-F62D-UL | | (Except FA-SC55V) | V | (Use FA-SC01U) | | | ✓ | v |
| IC-F1000/T/S, IC-F2000/T/S, IC-V10MR | | v | ✔(Use FA-SC28V for IC-V10MR) | (Use FA-SC02U) | | | ~ | v |
| IC-F3001, IC-F3003 IC-F4001, IC-F4003, IC-V3MR | | ✓ | Use FA-SC28V for IC-V3MR) | V (Use FA-SC01U or FA-SC03U) | | | ~ | ✓ |

| | STUBBY A | NTENNAS | | | SATELLITE + | GPS ANTENN | AS |
|--|--|--|-------------------------------------|-----------------------|--|---|---|
| MODEL NAME | FA-S81V5 136–150 MHz FA-S82V5 148–162 MHz FA-S83V5 160–174 MHz FA-S81U5 400–450 MHz FA-S81U5 400–450 MHz FA-S82U5 450–490 MHz | FA-SC26VS 136–144 MHz FA-SC27VS 142–150 MHz FA-SC56VS 150–162 MHz FA-SC57VS 160–174 MHz FA-SC73US 450–490 MHz FA-SC73US 450–490 MHz | FA-S103U Quick release connecter | FA-S102U | AH-38 OPC-2113 or user supplied coaxial cable required. | AH-40 1.5 m; 16.4 ft cable length | AH-41*16 OPC-2462 or user supplied coaxial cable required. |
| IC-SAT100 | | | ✓ | ✓ | ~ | V | V |
| IP730D, IP740D | | ✓ | | | | | |
| IP501H, IP504H | | | | | | | |
| IP100H | | | | | | | |
| IC-F7010T/S, IC-F7020T/S, IC-F7040T/S | V | | | | | | |
| IC-F3400DT/DS/D, IC-F4400DT/DS/D | ✓ | | | | | | |
| IC-F3261DT/DS, IC-F3263DT/DS IC-F4261DT/DS, IC-F4263DT/DS | | ✓ | | | | | |
| IC-F52D, IC-F62D | | ~ | | | | | |
| IC-F1100DT/DS/D, IC-F2100DT/DS/D | | ✓ | | | | | |
| IC-F3230DT/DS, IC-F4230DT/DS | | ✓ | | | | | |
| IC-F52D-UL, IC-F62D-UL | | ✓ | | | | | |
| IC-F1000/T/S, IC-F2000/T/S, IC-V10MR | | ✓ | | | | | |
| IC-F3001, IC-F3003 IC-F4001, IC-F4003, IC-V3MR | | ✓ | | | | | |

*13 Charging is possible while the case is attached. *14 LC-184 for use with IC-F3400DT/DS, IC-F4400DT/DS, LC-186 for use with IC-F3400D, IC-F4400D.
27 *15 Comes with DC power cable, AC adapter and adapter cable (DC to AC). *16 Supplied with 1.5 m, 4.9 ft coaxial cable, power box, AC adapter and mounting kit.

| | CC | DAXIAL CABLI | ES | ZONE COF | Y CABLES | APPLI | CATIONS | SPEAKERPHONE UNIT | PROGRAMMING SOFTWARE |
|--|--|---|---|----------------------------------|--------------------------------|---|---|-----------------------------|-------------------------------------|
| MODEL NAME | OPC-2422 For AH-40(5 m; 16.4 ft) | OPC-2462 For AH-41(59 m; 193.5 ft) | OPC-2113 For AH-38 (10 m, 32.8 ft) | OPC-1870 Handheld to handheld | OPC-2362 Handheld to mobile | RS-SAT100 For Android [™] For iOS [™] | IP500APP LTE radio mobile application* ¹⁷ | VE-SP1 | CS-V10MR CS-V3MR For Windows™ |
| | Ò | | Ø | | \bigcap | | | (IP radio is not supplied.) | |
| IC-SAT100 | ✓ | ✓ | ✓ | | | ~ | | | |
| IP730D, IP740D | | | | | | | ✓ | | |
| IP501H, IP504H | | | | | | | ✓ | ✓ | |
| IP100H | | | | | | | | | |
| IC-F7010T/S, IC-F7020T/S, IC-F7040T/S | | | | ~ | ~ | | | | |
| IC-F3400DT/DS/D, IC-F4400DT/DS/D | | | | ~ | ~ | | | | |
| IC-F3261DT/DS, IC-F3263DT/DS IC-F4261DT/DS, IC-F4263DT/DS | | | | ~ | | | | | |
| IC-F52D, IC-F62D | | | | ~ | | | | | |
| IC-F1100DT/DS/D, IC-F2100DT/DS/D | | | | | | | | | |
| IC-F3230DT/DS, IC-F4230DT/DS | | | | | | | | | |
| IC-F52D-UL, IC-F62D-UL | | | | ~ | | | | | |
| IC-F1000/T/S, IC-F2000/T/S, IC-V10MR | | | | | | | | | ✔ (Use CS-V10MR for IC-V10MR) |
| IC-F3001, IC-F3003 IC-F4001, IC-F4003, IC-V3MR | | | | | | | | | Use CS-V3MR for IC-V3MR) |

*¹⁷ For iOSTM: iOSTM version 12 or later. For AndroidTM: AndroidTM version 8.0 or later This service may not be available depending on the country/region.

Optional Accessories for Mobile Radios

| | | | | HAN | ID MICROPHO | NES | | | |
|--|-----------------------------------|---|-----------------------|-----------------------------|-------------------------------------|-----------------------|-----------------------------|----------------------------|---|
| MODEL NAME | HM-220 Heavy-duty type IP54 | HM-220T Heavy-duty type with DTMF keypad IP54 | HM-221 | HM-221T DTMF keypad type | HM-211 Active Noise Canceling | HM-152 | HM-152T DTMF keypad type | HM-148G Heavy-duty type | HM-148T Heavy-duty type with DTMF keypad |
| IC-SAT100M | | | | | | | | | |
| IP501M | | | | | | | | | |
| IC-F7510, IC-F7520, IC-F7540 | V | ✓ | ✓ | V | | | | | |
| IC-F9511HT | | | | | ~ | ~ | ~ | ~ | ✓ |
| IC-F5400D, IC-F6400D | ✓ | ✓ | ✓ | V | | | | | |
| IC-F5400DS, IC-F6400DS | ✓ | ✓ | ✓ | ~ | | | | | |
| IC-F5061/D, IC-F5063/D IC-F6061/D, IC-F6063/D | | | | | ~ | ✓ | ~ | ~ | ✓ |
| IC-F5330D, IC-F6330D | | | | | | | | | |
| IC-F5121D, IC-F5123D IC-F6121D, IC-F6123D | | | | | ~ | ~ | ~ | ~ | ✓ |
| IC-F5021, IC-F5023/H IC-F6021, IC-F6023/H | | | | | | ✓ | ~ | ~ | ✓ |
| IC-F5011, IC-F5013/H IC-F6011, IC-F6013/H | | | | | | ✓ | V | ~ | ✓ |

| | SPEAKER-MICROPHONE | HEADSET | DESKTOP MI | CROPHONES | EXTERNAL | SPEAKERS | SEPARAT | ION KITS |
|--|--------------------|----------------------------|-----------------------|----------------|-----------------------|--|--|--|
| MODEL NAME | HM-241 | VS-3 Bluetooth® headset | 5M-29 | 5M-26 5M-28 | SP-30 | SP-35 With 2 m; 6.5 ft cable SP-35L With 6 m; 19.7 ft cable | | RMK-7 Dual-head |
| IC-SAT100M | | ~ | | | ~ | ✓ | | |
| IP501M | ~ | ~ | | V(Use SM-28) | ~ | ~ | | |
| IC-F7510, IC-F7520, IC-F7540 | | ✓ | ✓ | | ✓ | ✓ | (Separation cable is required) | (Separation cable is required) |
| IC-F9511HT | | | | V(Use SM-26) | ~ | ~ | | |
| IC-F5400D, IC-F6400D | | | ✓ | | ✓ | ✓ | (Separation cable is required) | (Separation cable is required) |
| IC-F5400DS, IC-F6400DS | | | ~ | | ~ | ~ | | |
| IC-F5061/D, IC-F5063/D IC-F6061/D, IC-F6063/D | | | | V(Use SM-26) | ✓ | ~ | | |
| IC-F5330D, IC-F6330D | | ~ | | | ~ | ✓ | | |
| IC-F5121D, IC-F5123D IC-F6121D, IC-F6123D | | | | V(Use SM-26) | ✓ | ✓ | | |
| IC-F5021, IC-F5023/H IC-F6021, IC-F6023/H | | | | V(Use SM-26) | | ✓ | | |
| IC-F5011, IC-F5013/H IC-F6011, IC-F6013/H | | | | V(Use SM-26) | ~ | ✓ | | |

Optional Accessories for Mobile Radios

| | SEPARATION KITS | СОММА | NDMIC™ | SEP | ARATION CAB | LES | GPS ANTENNA | ACC C | ABLES |
|--|-----------------------|--|----------|--|---|--|--|-------------------------------|-------------------------------|
| MODEL NAME | RMK-3 | HM-218 Secondary controller for use with RMK-5 IP55 | НМ-230НВ | OPC-2367 8 m; 26.2 ft OPC-2366 5 m; 16.4 ft OPC-2365 3 m; 9.8 ft OPC-2364 1.9 m; 6.2 ft | OPC-2373 1.9 m; 6.2 ft OPC-2374 8 m; 26.2 ft | OPC-608 8 m; 26.2 ft OPC-726 5 m; 16.4 ft OPC-607 3 m; 9.8 ft OPC-609 1.9 m; 6.2 ft | UX-241 5 m; 16.4 ft cable length | OPC-1939 D-SUB 15-pin type | OPC-2078 D-SUB 25-pin type |
| IC-SAT100M | | | | | | | | | |
| IP501M | | | ~ | | | | | | |
| IC-F7510, IC-F7520, IC-F7540 | | (Separation cable is required) | | ✔ (Use with RMK-5 or RMK-7) | (Use with HM-218) | | ✓ | | |
| IC-F9511HT | | | | | | ~ | | | |
| IC-F5400D, IC-F6400D | | (Separation cable is required) | | ✔(Use with RMK-5 or RMK-7) | V(Use with HM-218) | | v | | |
| IC-F5400DS, IC-F6400DS | | | | | | | ~ | | |
| IC-F5061/D, IC-F5063/D IC-F6061/D, IC-F6063/D | ✓ | | | | | ✔(Use with RMK-3) | | | |
| IC-F5330D, IC-F6330D | | | | | | | | ✓ *18 | ✓* ¹⁸ |
| IC-F5121D, IC-F5123D IC-F6121D, IC-F6123D | | | | | | | | ✓ *18 | ✔* ¹⁸ |
| IC-F5021, IC-F5023/H IC-F6021, IC-F6023/H | | | | | | | | ✓ | ~ |
| IC-F5011, IC-F5013/H IC-F6011, IC-F6013/H | | | | | | | | ✓ | ~ |

| | ACC CABLES | ZONE COP | Y CABLES | MICROPHO | NE CABLES | SAT ANTENNA | COAXIAL CABLE | AC ADAPTER | APPLICATION |
|--|--------------------------------------|--------------------------------|---|--|---|---|---|------------------------------|---------------------------------------|
| MODEL NAME | OPC-2407 D-SUB 25-pin type | OPC-2362 Mobile to handheld | OPC-1871 Mobile to handheld OPC-1532 Mobile to | OPC-2355 2.5 m; 8.2 ft cable length | OPC-2429 For use with the supplied speaker microphone (2 m, 6.5 ft) | AH-40 Satellite + GPS antenna (1.5 m; 16.4 ft cable) | OPC-2422 For AH-40 (5 m; 16.4 ft) | BC-1575 12 V/7.5 A | RS-SAT100 For Android™ For iOS™ |
| | | | (Photo shows OPC-1871) | ? | Q | Ø | Ó | Pr. | |
| IC-SAT100M | | | | | ~ | ~ | ~ | ~ | ~ |
| IP501M | ✓ | | | (Use with HM-230HB or HM-241) | | | | | |
| IC-F7510, IC-F7520, IC-F7540 | | ✓ | | | | | | | |
| IC-F9511HT | | | ~ | | | | | | |
| IC-F5400D, IC-F6400D | | ~ | | | | | | | |
| IC-F5400DS, IC-F6400DS | | ~ | | | | | | | |
| IC-F5061/D, IC-F5063/D IC-F6061/D, IC-F6063/D | | | | | | | | | |
| IC-F5330D, IC-F6330D | | | | | | | | | |
| IC-F5121D, IC-F5123D IC-F6121D, IC-F6123D | | | | | | | | | |
| IC-F5021, IC-F5023/H IC-F6021, IC-F6023/H | | | | | | | | | |
| IC-F5011, IC-F5013/H IC-F6011, IC-F6013/H | | | | | | | | | |


*18 Digital modulation input is not available even when using accessory cables.

Activation Keys for Handheld and Mobile Radios

| | | ACTIVATION KEYS | | | | | | | | | |
|---------------------------------------|---------------------------------------|---|---|--|--|--|---|--|--|--|--|
| MODEL NAME | ISL-3 APCO P25 Trunking Phase 1 | ISL-P25TR APCO P25 Trunking Phase 1 | ISL-P25P2 APCO P25 Trunking Phase 2 | ISL-P25AES AES Encryption Activation Key | ISL-P25VS APCO P25 Conventional Voting Scan | ISL-P25DS APCO P25 Packet Data Service (GPS/Text) | ISL-P25FP Front Panel Programming | ISL-P25W 25 kHz Activation Key (for USA version transceivers) | | | |
| IC-F7010T/S, IC-F7020T/S, IC-F7040T/S | | ✓ | ~ | (Use with UT-134) | ~ | ✓ | ✓ | ✓ | | | |
| IC-F7510, IC-F7520, IC-F7540 | | ~ | ~ | (Use with UT-134) | ~ | ~ | ~ | ✓ | | | |
| IC-F9511HT | V | | | | | | | | | | |

| | | AC | TIVATION KE | YS | |
|-------------------------------------|--|---|---|--|---|
| MODEL NAME | ISL-UGMTR NXDN™ Type-D Trunking Upgrade Key | ISL-AKAES AES Encryption Activation Key | ISL-CHEX Channel Expan- sion Key increases channel number up to 4000 | ISL-AKSTM Dealer Set Mode Activation Key | ISL-AK25K 25 kHz Activation Key (for USA ver- sion transceivers) |
| IC-F3400DT/DS/D, IC-F4400DT/DS/D | ~ | (Use with UT-134) | ✓ | ~ | ~ |
| IC-F52D, IC-F62D | ~ | | | | ~ |
| IC-F52D-UL, IC-F62D-UL | ✓ | | | | ~ |
| IC-F5400D/DS, IC-F6400D/DS | ~ | ✔ (Use with UT-134) | ~ | ~ | ~ |

Optional Accessories for Repeaters



*19 The following versions are available. #11: CF card not included (Type-D single-site trunking) #12: CF-FR5000MC included #13: CF-FR5000MT included #14: CF-FR5300SC included

Optional Accessories for RoIP Gateway and IP Products

| | AC AD | APTERS | | | AUDIO CONNE | ECTION CABLES | 5 | |
|------------|-----------------------|---------------------------|---|---|---|--|---|--|
| MODEL NAME | BC-2075 12 V/4.2 A | BC-1475*20 12 V/0.25 A | OPC-2273 For VHF marine transceiver 5 m; 16.4 ft | OPC-2390 For IC-FR5000 series 5 m; 16.4 ft | OPC-2275 For mobile trans- ceiver 5 m; 16.4 ft | OPC-2276 For HM-152 or SM-26 5 m; 16.4 ft | OPC-2389 For RS-232 serial connection 5 m; 16.4 ft | OPC-2412 For IC-SAT100 5 m; 16.4 ft |
| VE-PG4 | | | V | V | v | V | ✓ | ✓ |
| AP-95M | V | | | | | | | |
| IP100FS | | (Use with CT-23) | | | | | | |
| RC-FS10 | | (Use with CT-23) | | | | | | |

| | SPEAKER-MICROPHONE | HA | ND MICROPHO | NES | DESKTOP MICROPHONE | DIGITAL VOICE CONVERTER | MICROPHONE ADAPTER | ACCESS POINT MANAGER |
|------------|-----------------------|------------------------------|-----------------------------|-------------------------|------------------------------|---|------------------------------|----------------------|
| MODEL NAME | HM-241 | HM-152 | HM-152T DTMF keypad type | HM-216 Short cable*2 | SM-26 | CT-24 For more than five digital radio con- nections | CT-23 | RS-AP3 |
| VE-PG4 | ✓ | ✓*21 | ✓*21 | ✓*21 | ✓*21 | ✓ | | |
| AP-95M | | | | | | | | ~ |
| IP100FS | | (Use with CT-23 and BC-147S) | | | (Use with CT-23 and BC-147S) | | ✔ (Use with SM-26 or HM-152) | |
| RC-FS10 | | (Use with CT-23 and BC-147S) | | | (Use with CT-23 and BC-147S) | | (Use with SM-26 or HM-152) | |

*²⁰ BC-147SA for the USA plug. SE for European plug. SV for Australian plug. *²¹ The HM-152, HM-152T, HM-216 and SM-26 has no Speaker function. An external speaker is required to be connected to the VE-PG4 to hear received audio with these accessories.

⁴²² The HM-216 has a total of 490 mm cable length including a 300 mm curl code, while the HM-152 has a total of 900 mm cable length.

Optional Accessories for HF Radio

| | HAND MICROPHONE | REMOTE CONTROL MIC | SEPARATION KIT | SEPARATION CA | BLES | AUTOTUNING ANTENNA | EXTERNAL | SPEAKERS |
|------------|----------------------------|--------------------|---|---|------------------|--------------------------------------|-----------------------|--|
| MODEL NAME | Нм-193 | HM-192 | RMK-6 For controller attached version | OPC-608 8 m; 2 OPC-726 5 m; 1 OPC-607 3 m; 9 OPC-609 19 m; | 6.4 ft 9.8 ft | AH-740 2.5-30 MHz Compact type | SP-30 | SP-35 With 2 m; 6.5 ft cable SP-35L With 6 m; 19.7 ft cable |
| IC-F8101 | V | V | v | ~ | | ✓ | ✓ | v |
| | | | | | | | | · |
| | GPS UNIT | GPS/MODEM CABLE | ANTENNA TUNER | ANTENNA ELEN | MENT | SHIELDED CONTROL CABLE | MOUNTING BRACKET | COOLING FAN |
| MODEL NAME | UX-248 Can be used with | OPC-2308 | AT-140 | AH-2b | | OPC-2309 10 m; 32.8 ft | MB-126 | CFU-F8100 |

| MODEL NAME | Can be used with Enhanced version. | 0PC-2308 | AI-140 | AH-20 | 10 m; 32.8 ft | MB-120 | CFU-F8100 |
|------------|---------------------------------------|-----------------------|--------|-------------------|-------------------|--------|-----------|
| | *8* | | | | 19 | | QQ. |
| IC-F8101 | V | ✓ | ~ | (Use with AT-140) | (Use with AT-140) | V | v |

: Not applicable 30

: Applicable

Some options may not be available in some countries. Please ask your dealer for details.

Read all instructions enclosed with the transceiver carefully and completely before using the transceiver.